


Dual SRL Bracket

Part #: 11058



Attachment:

1. Open Dual SRL Bracket by simultaneously pressing release buttons at end of pin and at bracket loop.



2. Install compatible SRLs directly to bracket loop as shown. Do not install with carabiners. Maximum 2 SRLs per Dual SRL Bracket.

3. At webbing under harness dorsal D-ring, insert locking pin beneath webbing as shown.


Never connect Dual SRL Bracket to harness D-ring.

4. Fully close and lock Dual SRL Bracket. Ensure green indicator is fully visible when locked.
ONLY for use with the following Guardian Fall Protection SRLs:

Diablo Web SRL
Diablo LE Cable SRL
10' Cable Velocity SRL
11' Halo Web SRL
GR6 Series SRLs

NEVER for use with any other fall protection device, unless explicitly permitted by Guardian.

Install close-up



Locking pin inserted through harness webbing under dorsal D-ring

SRLs connected to bracket loop



Green indicator fully visible